



## **Accel Hydrotherapy+ Footbath/Tub Cleaner**

- Recommended **disinfectant** cleaner to use in footbaths, pedicure baths or any type of soaking tub.
- Highly recommended to use after each pedicure.

### **DIRECTIONS FOR USE:**

**INITIAL PURGING:** Fill the tub with cool water to above the water jet line. Add **Accel** Hydrotherapy at 1:16 (235ml of **Accel** Hydrotherapy to 4 litres of water). Circulate tub for **up to 15** minutes to remove **possible** accumulated Biofilm. Drain and then rinse with cool water. This step may have to be repeated depending upon the level of contamination and age of equipment. Thoroughly clean the tub of remaining debris.

**BROAD-SPECTRUM SANITIZING FOR REGULAR MAINTENANCE BETWEEN CLIENTS:** Fill the tub with cool water to above the water jet line. Add **Accel** Hydrotherapy at 1:128 (30 ml of hydrotherapy to 4 litres of water). Ensure surfaces are scrubbed with an appropriate brush or a cloth. Circulate tub for 30 seconds. Drain and then rinse with cool water. Disinfect tub with Accel TB surface spray or wipe.

**END OF THE DAY DISINFECTING AND PREVENTION OF BIOFILM BUILD-UP:** Fill the tub with cool water to above the water jet line. Add **Accel** Hydrotherapy at 1:16 (235 ml of **Accel** Hydrotherapy to 4 litres of water). Circulate tub for 5 minutes. Drain and then rinse with cool water.

**DISINFECTING AND REMOVAL OF BIOFILMS (if left for three or more days):** Fill the tub with cool water to above the water jet line. Add **Accel** Hydrotherapy at 1:16 (235ml of **Accel** Hydrotherapy to 4 litres of water). Circulate tub for 5 minutes. Drain and then rinse with cool water.

**NOTE:** If excess foaming is a problem, add silicone-based antifoam of up to 5% the amount of **Accel** Hydrotherapy before starting jets.