



## **Accel Foot Bath Cleaner**

- ∞ Recommended cleaner to use in foot baths, pedicure baths or any type of soaking tub.
- ∞ Highly recommended to use after each pedicure.
- ∞ Use as the cleaning step prior to disinfecting the foot bath.

### **PROTOCOLS FOR CLEANING & DISINFECTING WHIRLPOOL FOOT BATHS AND AIR JET BASINS:**

#### **After every client:**

1. **Drain** all water from the basin.
2. **Scrub** all visible residue from the inside walls of the basin with a brush and liquid soap and water. Use a clean and disinfected brush with a handle. Brushes must be cleaned and disinfected after each use.
3. **Rinse** the basin with clean water.
4. **Refill the basin** with clean water and **circulate ACCEL FOOT BATH CLEANER at 1:128 dilution (1 oz)** through the basin for **5 minutes**.
5. **Drain, rinse** and **wipe** dry with a clean **paper** towel.
6. **Disinfect** the tub with an EPA registered disinfectant according to manufacturers directions. Allow for recommended contact time.
7. Rinse thoroughly.

#### **At the end of every day:**

Remove the screen and any other removable parts (a screwdriver may be necessary) and then:

1. **Clean** the screen and other removable parts and the area behind these with a brush and liquid soap and water to remove all visible residue and **replace** properly cleaned screen and other removable parts.
2. **Fill** the basin with water and add **ACCEL FOOT BATH CLEANER at 1:64 dilution (2 oz)**. **Circulate** through the spa system for **5**

3. **minutes.** If excessive foaming occurs, discontinue circulation and let soak for the remainder of the 5 minutes.
4. **Drain** the soapy solution and **rinse** the basin.
5. **Drain, rinse** and wipe dry with a clean **paper** towel.
6. Allow the basin to dry completely.
7. **Disinfect** the tub with an EPA registered disinfectant according to manufacturers directions. Leave for recommended contact time.
8. Rinse thoroughly.

**First time using Accel Foot Bath Cleaner – Recommended at the end of the day!**

Remove the screen and any other removable parts (a screwdriver may be necessary) and then:

1. **Clean** the screen and other removable parts and the area behind these with a brush and liquid soap and water to remove all visible residue and **replace** properly cleaned screen and other removable parts.
2. **Fill the basin** with clean water and **circulate **ACCEL FOOT BATH CLEANER** at 1:16 dilution (1 cup)** through the basin for **5 minutes.** If excessive foaming occurs, discontinue circulation and let soak for the remainder of the 5 minutes. Start up jets after 5 minutes to remove bio burden from the pipes.
3. **Drain, rinse** and wipe dry with a clean **paper** towel.
4. Allow the basin to dry completely.
5. **Disinfect** the tub with an EPA registered disinfectant according to manufacturers directions. Leave for recommended contact time.
6. Rinse thoroughly.